



# Application Chart

Type	Make	Year	Model	Part No	Track Width. (8)	Installation Notes
1	Anglia	1948 up	All Passenger Cars	MA4800	45 1/2"	(1)
1	Austin	1950-1952	Standard Passenger Car	MA5000	51 1/2"	
1	Buick	1928	Standard Passenger Car	MB2800	56 1/2"	
1	Buick	1936	Model 80 Roadmaster	MB3600	56 1/2"	
1	Chevrolet	1931	Standard Passenger Car	MC3100	56 1/2"	
1	Chevrolet	1934-1935	Standard Passenger Car	MC3435	56 1/2"	
1	Chevrolet	1934-1936	Master Passenger Car	MC3436M	56 1/2"	
1	Chevrolet	1936	Standard Passenger Car	MC3639	56 1/2"	
1	Chevrolet	1937-1939	All Passenger Cars	MC3639	56 1/2"	(6)
1	Chevrolet	1940-1948	All Passenger Cars	MC4048	56 1/2"	
1	Chevrolet	1949-1954	All Passenger Cars	MC4954	56 1/2"	(6)
4	Chevrolet	1955-1957	Passenger Cars	MC5557FC	58 1/2"	(2)(9)
5	Chevrolet	1962-1967	Nova, Chevy II	MN6267FC	56 1/2"	(10)
3	Chevrolet	1958-1962	Corvette	MV5862	58 1/2"	(11)
1	Chevy/GMC	1934-1936	Truck, Panel, Suburban	MC34-36P	56 1/2"	
1	Chevy/GMC	1937-1954	Truck, Panel, Suburban	MC3754P	56 1/2"	
2	Chevy/GMC	1955-1959	Truck, Panel, Suburban	MC5559P	59 1/2"	(2)
2	Chevy/GMC	1960-1966	Truck, Panel, Suburban	MC6066P	59 1/2"	(2)
2	Chevy/GMC	1973-1987	Truck, Blazer, Suburban	MC7800P	59 1/2"	(2)
1	Chrysler	1937	Passenger Car	MC3700	56 1/2"	
1	Diamond T	1938	Trucks	MDT3800	56 1/2"	
1	Dodge	1929	Passenger Cars	MD2900	56 1/2"	
1	Dodge	1933	All Passenger Cars	MD3300	56 1/2"	
1	Dodge	1935	All Passenger Cars	MD3500	56 1/2"	
1	Dodge	1934	All Passenger Cars	MD3400	56 1/2"	
1	Dodge	1936	All Passenger Cars	MD3600	56 1/2"	
1	Dodge	1936	Truck, Panel	MD3600P	56 1/2"	
1	Dodge	1937-1938	All Passenger Cars	MD3738	56 1/2"	
1	Dodge	1938	Truck, Panel	MD3800P	56 1/2"	
4	Dodge	1939-1941	Passenger Cars (117" w.b.)	MD3900FC	56 1/2"	(9)
1	Dodge/Fargo	1941-1949	Truck, Panel	MD4147P	56 1/2"	
2	Dodge/Fargo	1950-1952	Truck, Panel	MD5000P	58 1/2" or 59 1/2"	(2)(4)
2	Dodge/Fargo	1954-1955	Truck, Panel	MD5455P	59 1/2"	(2)
1	Essex	1925-1927	Passenger Car	ME2500	56 1/2"	(3)
1	Fiat	1981	Spyder	MF18100	56 1/2"	
1	Ford	1926-1927	Model T	MT-2700C		
1	Ford	1928-1931	Model A	MF2831	56 1/2"	(3)
1	Ford	1933-1934	All Passenger Cars	MF3334	56 1/2"	
1	Ford	1935-1940	All passenger Cars	MF3540	56 1/2"	(6)
1	Ford	1935-1941	Truck, Panel	MF3540	56 1/2"	(6)
1	Ford	1941-1948	All Passenger Cars	MF4148	56 1/2"	(6)
4	Ford	1949-1951	All Passenger Cars	MF4951FC	58 1/2"	(2)(9)
1	Ford	1955-1956	Passenger Car	MF5556	60 1/2"	(7)
2	Ford	1946-1952	Truck, Panel	MF4652P	58 1/2"	(2)
2	Ford	1953-1956	Truck, Panel	MF5356P	59 1/2"	(2)
2	Ford	1957-1961	Truck, Panel	MF5761P	59 1/2"	(2)
2	Ford	1962-1966	Truck, Panel	MF6266P	59 1/2"	(2)
2	Ford	1964-1970	Mustang	MF6470	58 1/2"	(2)
1	Ford	1965	Comet	MFC6500	56 1/2"	
1	Ford	1966	Falcon	MF6600	56 1/2"	
1	Ford	1961-1964	Falcon	MF6164	56 1/2"	
2	Ford	1963-1965	Fairlane	MF6365	58 1/2"	(2)
2	Ford	1966 -1967	Fairlane	MF6667	60 1/2"	(2)
1	Hudson	1937	Car	MH3700	56 1/2"	





# Application Chart

Type	Make	Year	Model	Part No	Track Width. (8)	Installation Notes
1	International	1937-1938	Truck	MI3800	56 1/2"	
1	International	1942-1955	KB Truck	MI4249	56 1/2"	
1	International	1950-1959	Truck	MI5503P	56 1/2" or 58 1/2"	(4)
2	Lincoln	1938-1939	Zephyr	ML3900	58 1/2"	(2)
1	Mercury	1939-1940	Passenger Car	MM3940	56 1/2"	
1	Mercury	1941	Passenger Car	MM4100	56 1/2"	
1	Merc/Monarch	1946-1948	Passenger Car	MM4648	56 1/2"	
2	Mercury	1952-1954	Passenger Car	MM5254	57 1/2"	(2)(3)(7)
2	Nash	1937-1938	Lafayette	MN3738	56 1/2" or 58 1/2"	(2)
4	Merc	1949-1951	Passenger Car	MM4951	56 1/2"	(2)(9)
2	Packard	1936	Model 120B	MPK3600	60 1/2"	(2)(7)
2	Packard	1937	Model 115	MPK3700	60 1/2"	(2)(7)
1	Plymouth	1929	Passenger Car	MP2900	56 1/2"	(2)(7)
3	Plymouth	1932	Passenger Car	MP3200	56 1/2"	(3)
1	Plymouth	1933	Passenger Cars	MD3300	56 1/2"	
1	Plymouth	1935	Passenger Cars	MP3500	56 1/2"	
1	Plymouth	1936	Passenger Cars	MP3600	56 1/2"	
1	Plymouth	1937	Passenger Cars	MP3700	56 1/2"	(13)
1	Plymouth	1937-1938	Passenger Cars	MP3738	56 1/2"	(12)
4	Plymouth	1939-1941	Passenger Cars (117" w.b.)	MD3900FC	56 1/2"	(9)
1	Plymouth	1950	Passenger Cars	MP5000	56 1/2"	
1	Pontiac	1935	Passenger Cars	MPN3500	56 1/2"	
1	Pontiac	1940-1948	Passenger Cars	MC4048	56 1/2"	(5)
1	Pontiac	1949-1952	Passenger Cars	MC4954	56 1/2"	(5)
5	Pontiac	1962-67	Acadian	MN6267FC	56 1/2"	(10)
1	Studebaker	1937	Passenger Cars	MS3700	56 1/2"	
1	Studebaker	1952-1966	Most Passenger Cars	MS6300	56 1/2"	(7)
2	Studebaker	1949-1953	Truck	MS5300P	58 1/2"	(2)
2	Studebaker	1952-1963	Car	MS6300	58 1/2"	(2)
1	Thames	1948	Truck, Panel	MT4800	56 1/2"	(4)
1	Universal		2x3 Parallel Rail, 28" o/s	MU2328	56 1/2"	
1	Universal		2x4 Parallel Rail, 25" o/s	MU2425	56 1/2"	
1	Universal		2x4 Parallel Rail, 31" o/s	MU2431	56 1/2"	
1	Willys	1937-1940	Passenger Cars, Trucks	MW3740	56 1/2"	
1	Willys	1946	Passenger Cars, Trucks	MW4600	56 1/2"	

**Always more installations available - Please call!**

## Installation Notes:

- (1) Narrowed steering rack required
- (2) Inner tie-rod extensions required
- (3) Requires narrowed control arms
- (4) May fit other years
- (5) With Chevrolet Style frame
- (6) Available in "Low" version (1" lower at spindle). Add "L" after part number
- (7) Some frame modifications required
- (8) Hub face to Hub face using Mustang II rotors. Add 5/8" when using 11" brake kits
- (9) Weld-on Sub-frame assembly
- (10) Bolt-on Sub-frame assembly
- (11) Bolt-in Crossmember Kit
- (12) 29 1/2" frame width
- (13) 29" frame width

**6541 Gateway Boulevard NW, (103rd Street) Edmonton Alberta, Canada T6H 2J1**